



Coffee Grinder Maintenance for Integral Grinders

Your coffee grinder is designed to give you years of good service and to run in a quiet operation. Coffee by its nature varies from bean to bean, and sometimes a coffee bean can cause a grinder to jam. Listed below are a few trouble shooting aspects to look out for if your grinder is not working.

- Check the red switch is in the on position.
- Check there is coffee in the hopper and the slide is either removed from the machine or pushed fully into the machine.
- In the coffee silo that holds the ground coffee, there is a small white microswitch. It is possible for coffee dust to cause this to stick in the closed position. Push the switch and make sure it clicks in and out.
- If after all the above have been checked and the grinder still does not function, your installer will have made a mark where the set point of the grinder is. You will now need to adjust the grinder and when the motor begins to operate you need to reset the grinder in exactly the position that it was to start with. Begin by turning off the red switch and allow the grinder motor to cool down for 40 minutes. Then grasp the hopper and turn it anticlockwise, it will make a series of clicks as you rotate it. You need to rotate it 1 complete turn anticlockwise. Next, operate the red switch at which point the grinder should run. As soon as it does, turn off the red switch and turn the hopper back to its original marked position. Turn the red switch back on and the issue should be resolved.